

SMARC T3354 Processor SDK04010006

On this page:

- Building TI/Embedian's Yocto BSP Distribution
- Introduction
- Generating SSH Keys
 - Step 1. Check for SSH keys
 - Step 2. Generate a new SSH key
 - Step 3. Add your SSH key to Embedian Gitlab Server
- Overview of the meta-smarct335x-sdk04010006 Yocto Layer
- Setting Up the Tools and Build Environment
- Building the target platforms
- Setup SD Card
 - Install Bootloader
 - uEnv.txt based bootscript
 - Install Kernel zImage
 - Install Kernel Device Tree Binary
- Install Root File System and Kernel Modules
- Setup eMMC
 - Prepare for eMMC binaries from SD card (or NFS):
 - Install binaries for partition 1
 - Install Kernel Device Tree Binary
- Install Root File System
- Feed Packages
- Writing Bitbake Recipes
 - Example HelloWorld recipe using autotools
 - Example HelloWorld recipe using a single source file

Building TI/Embedian's Yocto BSP Distribution

Eric Lee

version 1.0a, 8/28/2016

Introduction

This document describes how Embedian builds a customized version of TI's AM335X official BSP release for Embedian's *SMARC-T3354* product platform based on TI's Processor SDK 04.01.00.06. The approach is to pull from Embedian's public facing GIT repository and build that using bitbake. The reason why we use this approach is that it allows co-development. The build output is comprised of binary images, feed packages, and an SDK for *SMARC-T3354* specific development.

TI makes their Processor-SDK-04.01.00.06 Arago build scripts available via the following GIT repository:

```
http://arago-project.org/git/projects/oe-layersetup.git
```

If you're interested in TI's overall Processor SDK build and test process you should analyze the following repository:

```
http://arago-project.org/git/projects/tisdk-build-scripts.git
```

It is this repository that actually pulls in the *oe-layersetup* project to perform the Linux Processor-SDK builds for TI's entire suite of ARM CortexA chips. In this document we are only concerned with the *oe-layersetup* project.

Generating SSH Keys

We recommend you use SSH keys to establish a secure connection between your computer and Embedian Gitlab server. The steps below will

walk you through generating an SSH key and then adding the public key to our Gitlab account.

Step 1. Check for SSH keys

First, we need to check for existing ssh keys on your computer. Open up Git Bash and run:

```
$ cd ~/.ssh
$ ls
# Lists the files in your .ssh directory
```

Check the directory listing to see if you have a file named either `id_rsa.pub` or `id_dsa.pub`. If you don't have either of those files go to **step 2**. Otherwise, you already have an existing keypair, and you can skip to **step 3**.

Step 2. Generate a new SSH key

To generate a new SSH key, enter the code below. We want the default settings so when asked to enter a file in which to save the key, just press enter.

```
$ ssh-keygen -t rsa -C "your_email@example.com"
# Creates a new ssh key, using the provided email as a label
# Generating public/private rsa key pair.
# Enter file in which to save the key (/c/Users/you/.ssh/id_rsa): [Press enter]
$ ssh-add id_rsa
```

Now you need to enter a passphrase.

```
Enter passphrase (empty for no passphrase): [Type a passphrase]
Enter same passphrase again: [Type passphrase again]
```

Which should give you something like this:

```
Your identification has been saved in /c/Users/you/.ssh/id_rsa.
Your public key has been saved in /c/Users/you/.ssh/id_rsa.pub.
The key fingerprint is:
01:0f:f4:3b:ca:85:d6:17:a1:7d:f0:68:9d:f0:a2:db your_email@example.com
```

Step 3. Add your SSH key to Embedian Gitlab Server

Copy the key to your clipboard.

```
$ cat ~/.ssh/id_rsa.pub
ssh-rsa AAAAB3NzaC1yc2EAAAADAQABAAQDQUEnh8uGpfxaZVU6+uE4bsDrs/tEE5/BPW7jMAxak
6qgOh6nUrQGBWS+VxMM2un3KzvwLRJSj8G4TnTK2CSmlBvR+X8ZeXNTyAdaDxULs/StVhH+QRtFEGy4o
iMIzvIlTyORY89jzhIsgZzwr0lnqoSeWWASd+59JWtFjVY0nwVNVtbek7NfuIGGAPaijO5Wnshr2uChB
Pk8ScGjQ3z4VqNXP6CWhCXTqIk7EQ17yX2GKd6FgEFrzae+5Jf63Xm8g6abbE3ytCrMT/jYy500j2XSg
6jlxSFnKcONAcfMTWkTXeG/OgeGeG5kZdtqryRtOlGmOeuQe1dd3I+Zz3JyT your_email@example.c
om
```

Go to [Embedian Git Server](#). At Profile Setting --> SSH Keys --> Add SSH Key

Paste your public key and press "Add Key" and your are done.

Overview of the meta-smarct335x-sdk04010006 Yocto Layer

The supplied meta-smarct335x-sdk-03-00-00-04 Yocto compliant layer has the following organization:

```
.
|-- conf
|   |-- layer.conf
|   |-- site.conf
|   |-- machine
|   |-- `-- smarct335x.conf
|-- README
|-- recipes-bsp
|   |-- u-boot
|   |   |-- u-boot-smarc.inc
|   |   |-- `-- u-boot-smarct335x_2017.01-smarct335x.bb
|-- recipes-core
|   |-- busybox
|   |   |-- busybox_1.23.1.bbappend
|   |   |   |-- busybox
|   |   |   |-- `-- defconfig
|   |-- images
|   |   |-- meta-toolchain-smarc-tisdk.bb
|   |   |-- smarc-image.inc
|   |   |-- meta-toolchain-smarc-tisdk.inc
|   |   |-- `-- smarct335x-rootfs-image.bb
|   |-- `-- packagegroups
|   |   |-- packagegroup-smarc-console.bb
|   |   |-- packagegroup-smarc-tisdk-addons.bb
|   |   |-- `-- packagegroup-smarct335x-sdk.bb
|-- `-- recipes-kernel
|   |-- linux
|   |   |-- cmem.inc
|   |   |-- ti-uio.inc
|   |   |-- setup-defconfig.inc
|   |   |-- copy-defconfig.inc
|   |   |-- linux-smarct335x-staging_4.9.bb
|   |   |-- `-- linux-smarct335x-staging-4.9
|   |   |   |-- `-- defconfig
|   |-- `-- files
|   |   |-- configs
|   |   |   |-- `-- empty
|   |   |-- dra7xx
|   |   |   |-- am572x-pru-uio.dtsi
|   |   |   |-- cmem-dra71x.dtsi
|   |   |   |-- cmem.dtsi
|   |   |   |-- cmem-am571x.dtsi
|   |   |   |-- `-- cmem-dra72x.dtsi
|   |   |-- k2e
|   |   |   |-- cmem.dtsi
|   |   |   |-- `-- k2e-uio.dtsi
|   |   |-- k2g
|   |   |   |-- `-- cmem.dtsi
|   |   |-- k2hk
|   |   |   |-- cmem.dtsi
|   |   |   |-- `-- k2hk-uio.dtsi
|   |   |-- k21-evm
|   |   |   |-- cmem.dtsi
|   |   |   |-- `-- k21-uio.dtsi
|   |-- `-- keystone
```


if output is

```
multiarch
```

execute the following commands as it is else replace "multiarch" with the name of file present in that directory.

```
$ sudo sh -c "echo 'foreign-architecture i386' > /etc/dpkg/dpkg.cfg.d/multiarch"
```

The above command will add i386 architecture.

You'll also need to change the default shell to `bash` from Ubuntu's default `dash` shell (select the <No> option):

```
$ sudo dpkg-reconfigure dash
```

To build TI's am335x Processor-SDK-04.01.00.06 you will need to install the Linaro arm compiler that TI used for the release:

```
$ wget -c http://releases.linaro.org/components/toolchain/binaries/6.2-2016.11/arm-linux-gnueabi/gcc-linaro-6.2.1-2016.11-x86_64_arm-linux-gnueabi.tar.xz
$ sudo tar -C /opt -xJf gcc-linaro-6.2.1-2016.11-x86_64_arm-linux-gnueabi.tar.xz
```

Add the following `PATH` definition to the `.bashrc` file in your `$HOME` directory:

```
$ export PATH=/opt/gcc-linaro-6.2.1-2016.11-x86_64_arm-linux-gnueabi/bin:$PATH
```

Next clone and initialize TI's am335x SDK build process:

```
$ git clone http://arago-project.org/git/projects/oe-layersetup.git smarct3x-sdk-04.01.00.06
$ cd smarct3x-sdk-04.01.00.06
$ git checkout -b smarct3x-processor-sdk-04.01.00.06 acbcedb4911f3e6804610c757f56b7dfd4e31086
$ ./oe-layertool-setup.sh -f configs/processor-sdk/processor-sdk-04.01.00.06-config.txt
```

Add the Embedian's `meta-smarct335x-sdk-04-01-00-06` layer to the build process.

```
$ cd ~/smarct3x-sdk-04.01.00.06/sources
$ git clone git@git.embedian.com:developer/meta-smarct335x-sdk04010006.git -b smarct3x-processor-sdk-04.01.00.06
$ cd ~/smarct3x-processor-sdk-04.01.00.06/build
```

Edit the `~/smarct3x-sdk-04.01.00.06/build/conf/bblayers.conf` file to include the `meta-smarct335x-sdk04010006` layer in the layer list. It should look something like this (the example reflects the absolute paths on my machine):

```
# This template file was created by taking the oe-core/meta/conf/bblayers.conf
# file and removing the BBLAYERS section at the end.

# LAYER_CONF_VERSION is increased each time build/conf/bblayers.conf
# changes incompatibly
LCONF_VERSION = "7"

BBPATH = "${TOPDIR}"
BBFILES ?= ""

# Layers configured by oe-core-setup script
BBLAYERS += " \
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-smarct335x-sdk04010006 \
```

```
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-processor-sdk \  
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-arago/meta-arago-distro \  
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-arago/meta-arago-extras \  
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-browser \  
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-openamp \  
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-qt5 \  
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-openembedded/meta-networking \  
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-openembedded/meta-ruby \  
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-openembedded/meta-python \  
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-openembedded/meta-oe \  
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-openembedded/meta-gnome \  
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-ti \  
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-linaro/meta-linaro-toolchain \  
/home/eric/smarct3x-sdk-04.01.00.06/sources/meta-linaro/meta-optee \  
/home/eric/smarct3x-sdk-04.01.00.06/sources/oe-core/meta \  
  
"
```

Building the target platforms

To build the Embedian SMARC-T335X developer board images, respectively, use the following commands:

```
$ cd ~/smarct3x-sdk-04.01.00.06/build  
$ source conf/setenv  
$ MACHINE=smarct335x bitbake -k smarct335x-rootfs-image
```



Note

1. The first clean build might take more than 10 hours. If you met errors during the building process, let it finish and usually build again should be fine.

Once it done, you can find all required images under `~/smarct3x-sdk-04.01.00.06/build/arago-tmp-external-linaro-toolchain/`
`deploy/images/smarct335x/`

You may want to build programs that aren't installed into a root file system so you can make them available via a feed site (described below.) To do this you can build the package directly and then build the package named `package-index` to add the new package to the feed site.

The following example builds the `minicom` program and makes it available on the feed site:

```
$ MACHINE=smarct335x bitbake minicom  
$ MACHINE=smarct335x bitbake package-index
```

Once the build(s) are completed you'll find the resulting images, feeds and licenses in folder `~/smarct3x-processor-sdk-04.01.00.06/build/arago-tmp-external-linaro-toolchain/`
`deploy/`

`images/smarct335x/*`

This folder contains the binary images for the root file system and the Embedian SMARC-T335X specific version of the am335X SDK. Specifically the images are:

`images/smarct335x/u-boot.img`

This u-boot bootloader binary for SMARC T335X

`images/smarct335x/MLO`

The "Stage 1 Boot Loader" for SMARC-T335X. Its purpose is load the Stage 2 Boot Loader (u-boot.img).

`images/smarct335x/zImage`

The kernel zImage for SMARC-T335X.

`images/smarct335x/zImage-am335x-smarct335x.dtb`

The device tree binary file for SMARC-T335X.

deploy/images/smarct335x/smarct335x-rootfs-image-smarct335x*

Embedian root file system images for software development on Embedian's SMARC-T335X platforms.

deploy/ipk/*

This folder contains all the packages used to construct the root file system images. They are in **opkg** format (similar format to Debian packages) and can be dynamically installed on the target platform via a properly constructed **feed** file. Here is an example of the feed file (named **base-feeds.conf**) that is used internally at Embedian to install upgrades onto a **smarct335x** platform without reflashing the file system:

```
src/gz smarct335x http://www.embedian.com/core-sdk/smarct335x/processor-sdk-04.01.00.06/deploy/ipk/all
src/gz armv7ahf-neon http://www.embedian.com/core-sdk/smarct335x/smarct3x-processor-sdk-04.01.00.06/deploy/ipk/armv7ahf-neon
src/gz smarct335x http://www.embedian.com/core-sdk/smarct335x/smarct3x-processor-sdk-04.01.00.06/deploy/ipk/smarct335x
```

deploy/licenses/*

A database of all licenses used in all packages built for the system.

deploy/sdk/arago-2017.06-armv7a-linux-gnueabi-tisdk.sh

The installer for ARM toolchain that was created for the target platform. In Embedian's case that means that the headers for the Boost libraries are baked into the tools. (Generate by meta-toolchain-smarc-tisdk image)

Setup SD Card

For these instructions, we are assuming: DISK=/dev/mmcblk0, "lsblk" is very useful for determining the device id.

```
$ export DISK=/dev/mmcblk0
```

Erase SD card:

```
$ sudo dd if=/dev/zero of=${DISK} bs=1M count=16
```

Create Partition Layout:

With util-linux v2.26, sfdisk was rewritten and is now based on libfdisk.

```
sfdisk
$ sudo sfdisk --version
sfdisk from util-linux 2.27.1
```

Create Partitions:

```
i sfdisk >=2.26.x
$ sudo sfdisk ${DISK} <<-__EOF__
1M,48M,0xE,*
',,-
__EOF__
```

```
i sfdisk <=2.25
$ sudo sfdisk --in-order --Linux --unit M ${DISK} <<-__EOF__
1,48,0xE,*
',,-
__EOF__
```

Format Partitions:

```
for: DISK=/dev/mmcblk0
$ sudo mkfs.vfat -F 16 ${DISK}p1 -n boot
$ sudo mkfs.ext4 ${DISK}p2 -L rootfs

for: DISK=/dev/sdX
$ sudo mkfs.vfat -F 16 ${DISK}1 -n boot
$ sudo mkfs.ext4 ${DISK}2 -L rootfs
```

Mount Partitions:

On some systems, these partitions may be auto-mounted...

```
$ sudo mkdir -p /media/boot/
$ sudo mkdir -p /media/rootfs/

for: DISK=/dev/mmcblk0
$ sudo mount ${DISK}p1 /media/boot/
$ sudo mount ${DISK}p2 /media/rootfs/

for: DISK=/dev/sdX
$ sudo mount ${DISK}1 /media/boot/
$ sudo mount ${DISK}2 /media/rootfs/
```

Install Bootloader

Copy MLO/u-boot.img to the boot partition

deploy/images

```
$ sudo cp -v MLO /media/boot/
$ sudo cp -v u-boot.img /media/boot/
```

uEnv.txt based bootscrip

Create "uEnv.txt" boot script: (vim uEnv.txt)

~/uEnv.txt

```
optargs="consoleblank=0 mem=512M"
#u-boot eMMC specific overrides; Angstrom Distribution (SMARC-T335X) 2014-05-20
kernel_file=zImage
initrd_file=initrd.img

loadaddr=0x82000000
initrd_addr=0x88080000
fdtaddr=0x88000000
fdtfile=am335x-smarct335x.dtb

initrd_high=0xffffffff
fdt_high=0xffffffff

loadimage=load mmc ${mmcdev}:${mmcpart} ${loadaddr} ${kernel_file}
loadinitrd=load mmc ${mmcdev}:${mmcpart} ${initrd_addr} ${initrd_file}; setenv initrd_size ${filesize}
loadfdt=load mmc ${mmcdev}:${mmcpart} ${fdtaddr} /dtbs/${fdtfile}
#

##Un-comment to enable systemd in Debian Wheezy
#optargs=quiet init=/lib/systemd/systemd

console=ttyS3,115200n8
mmcroot=/dev/mmcblk1p2 ro
mmcrootfstype=ext4 rootwait fixrtc
```



```

mmcargs=setenv bootargs console=${console} root=${mmcroot} rootfstype=${mmcroofstftype} ${optargs}

#zImage:
uenvcmd=run loadimage; run loadfdt; run mmcargs; bootz ${loadaddr} - ${fdtaddr}

#zImage + ulinitrd: where ulinitrd has to be generated on the running system.
#boot_fdt=run loadimage; run loadinitrd; run loadfdt
#uenvcmd=run boot_fdt; run mmcargs; bootz ${loadaddr} ${initrd_addr}:${initrd_size} ${fdtaddr}

###Begin Rootfs from NFS
#serverip=192.168.1.51
#rootpath=/srv/nfs/smarct335x/ubuntu1204/
#nfsopts=nolock,acdirmin=60
#netargs=setenv bootargs console=${console} ${optargs} root=/dev/nfs nfsroot=${serverip}:${rootpath},${nfsopts} rw ip=dhcp
##netboot=echo Loading kernel from SDCARD and booting from NFS ...; run loadimage; run netargs; bootz ${loadaddr} - ${fdtaddr}
##uenvcmd=run netboot
###End Rootfs from NFS

###Begin Load kernel from TFTP
#netmask=255.255.255.0
#ipaddr=192.168.1.65
#serverip=192.168.1.51
#netboot=echo Loading kernel and device tree from TFTP and booting from NFS ...; setenv autoload no; tftp ${loadaddr} ${kernel_file}; tftp
${fdtaddr} ${fdtfile}; run netargs; bootz ${loadaddr} - ${fdtaddr}
#uenvcmd=run netboot
###End Load kernel from TFTP

```

Install Kernel zImage

Copy zImage to the boot partition:

```
build/arago-tmp-external-linaro-toolchain/deploy/images/smarct335x
```

```
$ sudo cp -v zImage /media/boot
```

Install Kernel Device Tree Binary

```
build/arago-tmp-external-linaro-toolchain/deploy/images/smarct335x
```

```
$ sudo mkdir -p /media/boot/dtbs
```

```
$ sudo cp -v zImage-am335x-smarct335x.dtb /media/boot/dtbs/am335x-smarct335x.dtb
```

Install Root File System and Kernel Modules

```
build/arago-tmp-external-linaro-toolchain/deploy/images/smarct437x
```

```
$ sudo tar Jxvf smarct335x-rootfs-image-smarct335x.tar.xz -C /media/rootfs
```



Kernel modules are built into root filesystems.

Remove SD card:

```

$ sync
$ sudo umount /media/boot
$ sudo umount /media/rootfs

```

Setup eMMC

Setting up eMMC usually is the last step at development stage after the development work is done at your SD card or NFS environments. eMMC on module will be always emulated as /dev/mmcblk0. Setting up eMMC now is nothing but changing the device descriptor.

This section gives a step-by-step procedure to setup eMMC flash. Users can write a shell script your own at production to simplify the steps.

First, we need to backup the final firmware from your SD card or NFS.

Prepare for eMMC binaries from SD card (or NFS):

Insert SD card into your Linux PC. For these instructions, we are assuming: DISK=/dev/mmcblk0, "lsblk" is very useful for determining the device id.

For these instruction, we are assuming: DISK=/dev/mmcblk0, "lsblk" is very useful for determining the device id.

```
$ export DISK=/dev/mmcblk0
```

Mount Partitions:

On some systems, these partitions may be auto-mounted...

```
$ sudo mkdir -p /media/boot/
$ sudo mkdir -p /media/rootfs/

for: DISK=/dev/mmcblk0
$ sudo mount ${DISK}p1 /media/boot/
$ sudo mount ${DISK}p2 /media/rootfs/

for: DISK=/dev/sdX
$ sudo mount ${DISK}1 /media/boot/
$ sudo mount ${DISK}2 /media/rootfs/
```

Copy MLO to rootfs partition:

```
$ sudo cp -v /media/boot/MLO /media/rootfs/home/root
```

Copy u-boot.img to rootfs partition:

```
$ sudo cp -v /media/boot/u-boot.img /media/rootfs/home/root
```



The U-Boot for eMMC Boot up has one line difference in include/configs/smarct335x_evm.h. The mmcdev in SD boot up is 0 and is 1 in eMMC boot up. Please go to

recipes-bsp/u-boot/u-boot-smarct335x_2017.01-smarct335x.bb and make changes as follows.

```
# BRANCH = "v2017.01-smarct3x"
```

```
# SRCREV = "93e96ce2ff6bd0458bcf3ab2861832b277628277"
```

```
BRANCH = "v2017.01-smarct3x-emmc"
```

```
SRCREV = "3f80471242ce4c8754ab700a97a32111e17c96d7"
```

Copy zImage to rootfs partition:

```
arago-tmp-external-linaro-toolchain/deploy/images
$ sudo cp -v zImage /media/rootfs/home/root
```

Copy uEnv.txt to rootfs partition:

Copy and paste the following contents to /media/rootfs/home/root (\$ sudo vim /media/rootfs/home/root/uEnv.txt)

```
optargs="consoleblank=0 mem=512M"
#u-boot eMMC specific overrides; Angstrom Distribution (SMARC T335X) 2014-05-20
kernel_file=zImage
initrd_file=initrd.img
loadaddr=0x82000000
initrd_addr=0x88080000
fdtaddr=0x88000000
fdtfile=am335x-smarct335x.dtb
initrd_high=0xffffffff
fdt_high=0xffffffff
loadimage=load mmc ${mmcdev}:${mmcpart} ${loadaddr} ${kernel_file}
loadinitrd=load mmc ${mmcdev}:${mmcpart} ${initrd_addr} ${initrd_file}; setenv initrd_size ${filesize}
loadfdt=load mmc ${mmcdev}:${mmcpart} ${fdtaddr} /dtbs/${fdtfile}
#
##Un-comment to enable systemd in Debian Wheezy
#optargs=quiet init=/lib/systemd/systemd
console=tyS3,115200n8
#mmcroot=/dev/mmcblk0p2 ro
#mmcrootfstype=ext4 rootwait fixrtc
mmcroot=/dev/ram0
#mmcargs=setenv bootargs console=${console} root=${mmcroot} rootfstype=${mmcrootfstype} ${optargs}
mmcargs=setenv bootargs console=${console} root=${mmcroot} iniramfs=0x81000000, 8M
#zImage:
uenvcmd=run loadimage; run loadfdt; run mmcargs; bootz ${loadaddr} - ${fdtaddr}
#zImage + ulinitrd: where ulinitrd has to be generated on the running system.
#boot_fdt=run loadimage; run loadinitrd; run loadfdt
#uenvcmd=run boot_fdt; run mmcargs; bootz ${loadaddr} ${initrd_addr}:${initrd_size} ${fdtaddr}
###Begin Rootfs from NFS
#serverip=192.168.1.51
#rootpath=/srv/nfs/smarct335x/ubuntu1204/
#nfsopts=nolock,acdirmin=60
#netargs=setenv bootargs console=${console} ${optargs} root=/dev/nfs nfsroot=${serverip}:${rootpath},${nfsopts} rw ip=dhcp
##netboot=echo Loading kernel from SDCARD and booting from NFS ...; run loadimage; run netargs; bootz ${loadaddr} - ${fdtaddr}
##uenvcmd=run netboot
###End Rootfs from NFS
###Begin Load kernel from TFTP
#netmask=255.255.255.0
#ipaddr=192.168.1.65
#serverip=192.168.1.51
#netboot=echo Loading kernel and device tree from TFTP and booting from NFS ...; setenv autoload no; tftp ${loadaddr} ${kernel_file}; tftp
${fdtaddr} ${fdtfile}; run netargs; bootz ${loadaddr} - ${fdtaddr}
#uenvcmd=run netboot
###End Load kernel from TFTP
```

Copy real rootfs to rootfs partition:

```
$ pushd /media/rootfs
$ sudo tar cvfz ~/smarct335x-emmc-rootfs.tar.gz .
$ sudo mv ~/smarct335x-emmc-rootfs.tar.gz /media/rootfs/home/root
$ popd
```

Remove SD card:

```
$ sync
$ sudo umount /media/boot
$ sudo umount /media/rootfs
```

Insert this SD card into your SMARC T335X device and boot up from SD card.

Now it will be almost the same as you did when setup your SD card, but the eMMC device descriptor is /dev/mmcblk1 now.

```
$ export DISK=/dev/mmcblk0
```

Erase SD card:

```
$ sudo dd if=/dev/zero of=${DISK} bs=1M count=16
```

Create Partition Layout:

```
$ sudo sfdisk --in-order --Linux --unit M ${DISK} <<--__EOF__
1,48,0xE,*
,,,~
__EOF__
```

Format Partitions:

```
$ sudo mkfs.vfat -F 16 ${DISK}p1 -n boot
$ sudo mkfs.ext4 ${DISK}p2 -L rootfs
```

Mount Partitions:

```
$ sudo mkdir -p /media/boot/
$ sudo mkdir -p /media/rootfs/
$ sudo mount ${DISK}p1 /media/boot/
$ sudo mount ${DISK}p2 /media/rootfs/
```

Install binaries for partition 1

Copy MLO/u-boot.img/uEnv.txt/zImage to the boot partition

```
$ sudo cp -v MLO u-boot.img zImage uEnv.txt /media/boot/
```

Install Kernel Device Tree Binary

```
$ sudo mkdir -p /media/boot/dtbs
$ sudo cp -v am335x-smarct335x.dtb /media/boot/dtbs
```

Install Root File System

```
$ sudo tar -zxvf smarct335x-emmc-rootfs.tar.gz -C /media/rootfs
```

Unmount eMMC:

```
$ sync
$ sudo umount /media/boot
$ sudo umount /media/rootfs
```

Switch your Boot Select to eMMC and you will be able to boot up from eMMC now.

Feed Packages

The following procedure can be used on a Embedian *SMARC-T335X* device to download and utilize the feed file show above to install the *minicom* terminal emulation program:

```
# vim /etc/opkg/base-feeds.conf
```

Only keep the following three lines:

```
src/gz all http://www.embedian.com/core-sdk/smarct335x/smarct3x-processor-sdk-04.01.00.06/deploy/ipk/all
src/gz armv7ahf-neon http://www.embedian.com/core-sdk/smarct335x/smarct3x-processor-sdk-04.01.00.06/deploy/ipk/armv7ahf-neon
src/gz smarct335x http://www.embedian.com/core-sdk/smarct335x/smarct3x-processor-sdk-04.01.00.06/deploy/ipk/smarct335x
```

```
i # opkg update
# opkg upgrade
# opkg install minicom
```

Writing Bitbake Recipes

In order to package your application and include it in the root filesystem image, you must write a BitBake recipe for it.

When starting from scratch, it is easiest to learn by example from existing recipes.

Example HelloWorld recipe using autotools

For software that uses autotools (./configure; make; make install), writing recipes can be very simple:

```
DESCRIPTION = "Hello World Recipe using autotools"
HOMEPAGE = "http://www.embedian.com/"
SECTION = "console/utils"
PRIORITY = "optional"
LICENSE = "GPL"
PR = "r0"

SRC_URI =
"git://git@git.embedian.com/developer/helloworld-autotools.git;protocol=ssh;tag=v1.0"
S = "${WORKDIR}/git"

inherit autotools
```

`SRC_URI` specifies the location to download the source from. It can take the form of any standard URL using `http://`, `ftp://`, etc. It can also fetch from SCM systems, such as git in the example above.

`PR` is the package revision variable. Any time a recipe is updated that should require the package to be rebuilt, this variable should be incremented.

`inherit autotools` brings in support for the package to be built using autotools, and thus no other instructions on how to compile and install the software are needed unless something needs to be customized.

`S` is the source directory variable. This specifies where the source code will exist after it is fetched from `SRC_URI` and unpacked. The default value is `${WORKDIR}/${PN}-${PV}`, where `PN` is the package name and `PV` is the package version. Both `PN` and `PV` are set by default using the filename of the recipe, where the filename has the format `PN_PV.bb`.

Example HelloWorld recipe using a single source file

This example shows a simple case of building a `helloworld.c` file directly using the default compiler (`gcc`). Since it isn't using `autotools` or `make`, we have to tell BitBake how to build it explicitly.

```
DESCRIPTION = "HelloWorld"
SECTION = "examples"
LICENSE = "GPL"

SRC_URI = "file://helloworld.c"

S = "${WORKDIR}"

do_compile() {
    ${CC} ${CFLAGS} ${LDFLAGS} helloworld.c -o helloworld
}

do_install() {
    install -d ${D}${bindir}
    install -m 0755 helloworld ${D}${bindir}
}
```

In this case, `SRC_URI` specifies a file that must exist locally with the recipe. Since there is no code to download and unpack, we set `S` to `WORKDIR` since that is where `helloworld.c` will be copied to before it is built.

`WORKDIR` is located at `${OETREE}/build/arago-tmp-external-linaro-toolchain/work/armv7ahf-neon-linux-gnueabi/<package> name and version` for most packages. If the package is machine-specific (rather than generic for the `armv7ahf` architecture), it may be located in the `smarct335x-linux-gnueabi` subdirectory depending on your hardware (this applies to kernel packages, images, etc).

`do_compile` defines how to compile the source. In this case, we just call `gcc` directly. If it isn't defined, `do_compile` runs `make` in the source directory by default.

`do_install` defines how to install the application. This example runs `install` to create a `bin` directory where the application will be copied to and then copies the application there with permissions set to `755`.

`D` is the destination directory where the application is installed to before it is packaged.

`${bindir}` is the directory where most binary applications are installed, typically `/usr/bin`.

For a more in-depth explanation of BitBake recipes, syntax, and variables, see the [Recipe Chapter](#) of the OpenEmbedded User Manual.

-- End of Document --

version 1.0a, 08/28/2016

Last updated 2018-03-28