

SMARC-FiMX6

- Build and Install Linux System for SMARC-FiMX6 (Solo, Dual Lite, Dual and Quad Core)
- Availability
- Carrier Board
- Basic Resources
- ARM Cross Compiler: GCC
- Generating SSH Keys
 - Step 1. Check for SSH keys
 - Step 2. Generate a new SSH key
 - Step 3. Add your SSH key to Embedian Gitlab Server
- Bootloader: U-Boot
- Linux Kernel
- Root File System
- Setup SD Card
 - Install Bootloader
 - uEnv.txt based bootscript
 - Install Kernel zImage
 - Install Kernel Device Tree Binary
- Install Root File System and Kernel Modules
 - Copy Root File System:
 - Copy Kernel Modules:
- Setup eMMC
 - Prepare for eMMC binaries from SD card (or NFS):
 - Copy Binaries to eMMC from SD card:
 - Install binaries for partition 1
 - Install Kernel Device Tree Binary
- Install Root File System

Build and Install Linux System for *SMARC-FiMX6* (Solo, Dual Lite, Dual and Quad Core)

This document provides instructions for advanced users how Embedian offers patches and builds a customized version of u-boot and linux kernel for Embedian's *SMARC-FiMX6* product platform and how to install the images to bring the evaluation board up and running.

Our aim is to fully support our hardware through device drivers. We also provide unit tests so that testing a board is easy and custom development can start precisely.

Availability

SMARC-FiMX6 at Embedian

Carrier Board

SBC-SMART-BEE (module and carrier board) at Embedian

SBC-SMART-MEN (module and carrier board) at Embedian

EVK-STD-CARRIER (universal carrier board for all SMARC modules) at Embedian

Basic Resources

- ARM Cross Compiler
 - Linaro: <https://launchpad.net/linaro-toolchain-binaries>
- Bootloader
 - Das U-Boot – the Universal Boot Loader <http://www.denx.de/wiki/U-Boot>
 - Source – <http://git.denx.de/?p=u-boot.git;a=summary>

- Linux Kernel
 - Linus's Mainline tree: <http://git.kernel.org/?p=linux/kernel/git/torvalds/linux.git;a=summary>
 - Freescale Linux source tree: [git://git.freescale.com/imx/linux-2.6-imx.git](http://git.freescale.com/imx/linux-2.6-imx.git)
 - Freescale BSP meta layer: [git://git.freescale.com/imx/meta-fsl-bsp-release](http://git.freescale.com/imx/meta-fsl-bsp-release)
 - OpenEmbedded/Yocto BSP layer for Freescale's ARM platform [git://git.yoctoproject.org/meta-fsl-arm](http://git.yoctoproject.org/meta-fsl-arm)
 - Embedian SMARC-FiMX6 kernel source tree for linux 4.9.11_1.0.0, 4.1.15_1.0.0, 3.14.28_1.0.0: [git@git.embedian.com:developer/smarc-fsl-linux-kernel.git](http://git.embedian.com:developer/smarc-fsl-linux-kernel.git)
- ARM based rootfs
 - Debian Squeeze: <http://www.debian.org/>

ARM Cross Compiler: GCC

This is a pre-built (32bit) version of Linaro GCC that runs on generic linux, so 64bit users need to make sure they have installed the 32bit libraries for their distribution.

debian based	extra	pkgs: (sudo apt-get update ; sudo apt-get install xyz)
Ubuntu 12.04		ia32-libs
Debian 7 (Wheezy)	sudo dpkg --add-architecture i386	libc6:i386 libstdc++6:i386 libncurses5:i386 zli b1g:i386
Ubuntu 12.10 -> 14.04		libc6:i386 libstdc++6:i386 libncurses5:i386 zli b1g:i386
Red Hat/Centos/Fedora		libstdc++.i686 ncurses-devel.i686 zlib.i686
Red Hat based (rpm)	extra	pkgs: (yum install xyz)
Red Hat/Centos/Fedora		libstdc++.i686 ncurses-devel.i686 zlib.i686
Ubuntu 12.04		ia32-libs
Ubuntu 12.10 -> 14.04		libc6:i386 libstdc++6:i386 libncurses5:i386 zli b1g:i386

To build Embedian's *SMARC-FiMX6* u-boot and linux kernel, you will need to install the Linaro arm compiler that is the same as that we build for *SMARC-T335X*:

For u-boot 2017.03 and Linux 4.9.11, you need to use the following newer Linaro arm compiler.

```
$ wget -c https://releases.linaro.org/components/toolchain/binaries/6.2-2016.11/arm-linux-gnueabi/gcc-linaro-6.2.1-2016.11-x86_64_arm-linux-gnueabi.tar.xz
$ sudo tar -C /opt -xJf gcc-linaro-6.2.1-2016.11-x86_64_arm-linux-gnueabi.tar.xz
$ export CC=/opt/gcc-linaro-6.2.1-2016.11-x86_64_arm-linux-gnueabi/bin/arm-linux-gnueabi-
```

For u-boot 2015.04 and Linux 4.1.15

```
$ wget -c https://releases.linaro.org/archive/15.05/components/toolchain/binaries/arm-linux-gnueabi/gcc-linaro-4.9-2015.05-x86_64_arm-linux-gnueabi.tar.xz
$ sudo tar -C /opt -xJf gcc-linaro-4.9-2015.05-x86_64_arm-linux-gnueabi.tar.xz
$ export CC=/opt/gcc-linaro-4.9-2015.05-x86_64_arm-linux-gnueabi/bin/arm-linux-gnueabi-
```

For u-boot 2014.04, and Linux 3.14

```
$ wget http://releases.linaro.org/archive/13.04/components/toolchain/binaries/gcc-linaro-arm-linux-gnueabi-4.7-2013.04-20130415_linux.tar.xz
$ sudo tar -C /opt -xJf gcc-linaro-arm-linux-gnueabi-4.7-2013.04-20130415_linux.tar.xz
```

```
$ export CC=/opt/gcc-linaro-arm-linux-gnueabihf-4.7-2013.04-20130415_linux/bin/arm-linux-gnueabihf-
```

Test:

If this test fails, verify that you have the 32bit libraries installed on your development system.

```
$$ {CC}gcc --version
arm-linux-gnueabihf-gcc (crosstool-NG linaro-1.13.1-4.7-2013.04-20130415 - Linaro GCC 2013.04) 4.7.3 20130328 (prerelease)
Copyright (C) 2012 Free Software Foundation, Inc.
This is free software; see the source for copying conditions. There is NO
warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.
```

Generating SSH Keys

We recommend you use SSH keys to establish a secure connection between your computer and Embedian Gitlab server. The steps below will walk you through generating an SSH key and then adding the public key to our Gitlab account.

Step 1. Check for SSH keys

First, we need to check for existing ssh keys on your computer. Open up Git Bash and run:

```
$ cd ~/.ssh
$ ls
# Lists the files in your .ssh directory
```

Check the directory listing to see if you have a file named either `id_rsa.pub` or `id_dsa.pub`. If you don't have either of those files go to **step 2**. Otherwise, you already have an existing keypair, and you can skip to **step 3**.

Step 2. Generate a new SSH key

To generate a new SSH key, enter the code below. We want the default settings so when asked to enter a file in which to save the key, just press enter.

```
$ ssh-keygen -t rsa -C "your_email@example.com"
# Creates a new ssh key, using the provided email as a label
# Generating public/private rsa key pair.
# Enter file in which to save the key (/c/Users/you/.ssh/id_rsa): [Press enter]
$ ssh-add id_rsa
```

Now you need to enter a passphrase.

```
Enter passphrase (empty for no passphrase): [Type a passphrase]
Enter same passphrase again: [Type passphrase again]
```

Which should give you something like this:

```
Your identification has been saved in /c/Users/you/.ssh/id_rsa.
Your public key has been saved in /c/Users/you/.ssh/id_rsa.pub.
The key fingerprint is:
01:0f:f4:3b:ca:85:d6:17:a1:7d:f0:68:9d:f0:a2:db your_email@example.com
```

Step 3. Add your SSH key to Embedian Gitlab Server

Copy the key to your clipboard.

```
$ cat ~/.ssh/id_rsa.pub
ssh-rsa AAAAB3NzaC1yc2EAAAADAQABAAQDQUEnh8uGpfxaZVU6+uE4bsDrs/tEE5/BPW7jMAxak
6qgOh6nUrQGBWS+VxMM2un3KzwwLRJSj8G4TnTK2CSm1BvR+X8ZeXNTyAdaDxULs/StVhH+QRtFEGy4o
iMIzvIlTyORY89jzhIsgZzwr0lnqoSeWWASd+59JWtFjVy0nwVNVtbek7NfuIGGAPaijO5Wnshr2uChB
Pk8ScGjQ3z4VqNXP6CWhCXTqIk7EQ17yX2GKd6FgEFrzae+5Jf63Xm8g6abbE3ytCrMT/jYy500j2XSg
6jlxSFnKcONAcfMTWkTXeG/OgeGeG5kZdtqryRtOlGmOeuQe1dd3I+Zz3JyT your_email@example.c
om
```

Go to Embedian Git Server. At Profile Setting --> SSH Keys --> Add SSH Key

Paste your public key and press "Add Key" and you are done.

Bootloader: U-Boot

Clone the U-Boot source code from Embedian Git Server.

Download:

For u-boot v2017.03:

```
$ git clone git@git.embedian.com:developer/smarc-t335x-uboot.git smarcfmx6-uboot
$ cd smarcfmx6-uboot
$ git checkout smarc-imx_v2017.03_4.9.11_1.0.0_ga
```

For u-boot v2015.04:

```
$ git clone git@git.embedian.com:developer/smarc-t335x-uboot.git smarcfmx6-uboot
$ cd smarcfmx6-uboot
$ git checkout smarc-imx_v2015.04_4.1.15_1.0.0_ga
```

Configure and Build:

```
$ make ARCH=arm CROSS_COMPILE=${CC} distclean
$ make ARCH=arm CROSS_COMPILE=${CC} smarcfmx6_quad_1g_ser3_defconfig
$ make ARCH=arm CROSS_COMPILE=${CC}
```



Note **Note1:**

If the board is SMARC-FiMX6-Q-2G or SMARC-FiMX6-D-2G, use
\$ make ARCH=arm CROSS_COMPILE=\${CC} smarcfmx6_quad_2g_ser3_defconfig

If the board is SMARC-FiMX6-Q-1G or SMARC-FiMX6-D-1G, use
\$ make ARCH=arm CROSS_COMPILE=\${CC} smarcfmx6_quad_1g_ser3_defconfig

If the board is SMARC-FiMX6-U-1G, use
\$ make ARCH=arm CROSS_COMPILE=\${CC} smarcfmx6_dl_1g_ser3_defconfig

If the board is SMARC-FiMX6-S, use
\$ make ARCH=arm CROSS_COMPILE=\${CC} smarcfmx6_solo_ser3_defconfig

If the board is SMARC-FiMX6-QP-1G, use
\$ make ARCH=arm CROSS_COMPILE=\${CC} smarcfmx6_quadplus_1g_ser3_defconfig

If the board is SMARC-FiMX6-QP-2G, use
\$ make ARCH=arm CROSS_COMPILE=\${CC} smarcfmx6_quadplus_2g_ser3_defconfig

Note 2:

"ser3" stands for console debug port. In this example, we uses SER3 as debug port. If user uses SER0 as your debug port, make change to "ser0" instead. Same as SER1 and SER2.

Note 3:

The *SMARC-FiMX6* module always boot up from the onboard *SPI NOR* flash. The factory default will be *u-boot.imx* pre-installed. In some cases when the *SPI NOR* flash is empty or needs to be upgraded. Users can shunt crossed the *TEST#* to ground. In this way, the *SMARC-FiMX6* module will boot up to carrier SD card, if *TEST#* pin is shunt crossed. The *u-boot.imx* image are the same, the difference is how you flash *u-boot.imx*. This will be explained in the "Setup SD card" section.

For u-boot v2014.04:

```
$ git clone git@git.embedian.com:developer/smarc-t335x-uboot.git smarcfmx6-uboot
$ cd smarcfmx6-uboot
$ git checkout smarc-imx_v2014.04_3.14.28_1.0.0_ga
```

Configure and Build:

```
$ make ARCH=arm CROSS_COMPILE=${CC} distclean
$ make ARCH=arm CROSS_COMPILE=${CC} smarcfmx6_quad_1g_ser3_config
$ make ARCH=arm CROSS_COMPILE=${CC}
```



Note

Note 1:

If the board is SMARC-FiMX6-Q-2G or SMARC-FiMX6-D-2G, use
\$ make ARCH=arm CROSS_COMPILE=\${CC} smarcfmx6_quad_2g_ser3_config

If the board is SMARC-FiMX6-Q-1G or SMARC-FiMX6-D-1G, use
\$ make ARCH=arm CROSS_COMPILE=\${CC} smarcfmx6_quad_1g_ser3_config

If the board is SMARC-FiMX6-U-1G, use
\$ make ARCH=arm CROSS_COMPILE=\${CC} smarcfmx6_dl_1g_ser3_config

If the board is SMARC-FiMX6-S, use
\$ make ARCH=arm CROSS_COMPILE=\${CC} smarcfmx6_solo_ser3_config

Note 2:

"ser3" stands for console debug port. In this example, we uses SER3 as debug port. If user uses SER0 as your debug port, make change to "ser0" instead. Same as SER1 and SER2.

Note 3:

The *SMARC-FiMX6* module always boot up from the onboard *SPI NOR* flash. The factory default will be *u-boot.imx* pre-installed. In some cases when the *SPI NOR* flash is empty or needs to be upgraded. Users can shunt crossed the *TEST#* to ground. In this way, the *SMARC-FiMX6* module will boot up to carrier SD card, if *TEST#* pin is shunt crossed. The *u-boot.imx* image are the same, the difference is how you flash *u-boot.imx*. This will be explained in the "Setup SD card" section.

Linux Kernel

Download:

[For 4.9.11 \(Based on Freescale imx 4.9.11 1.0.0 ga official release\):](#)

```
$ git clone git@git.embedian.com:developer/smarc-fsl-linux-kernel.git
$ cd smarc-fsl-linux-kernel
$ git checkout smarc-imx_4.9.11_1.0.0_ga
```

Configure and Build:

```
$ make ARCH=arm CROSS_COMPILE=${CC} distclean
$ make ARCH=arm CROSS_COMPILE=${CC} smarcfmx6_defconfig
$ make ARCH=arm CROSS_COMPILE=${CC} zImage modules imx6q-smarcfmx6.dtb imx6dl-smarcfmx6.dtb imx6qp-smarcfmx6.dtb
```

For 4.1.15 (Based on Freescale imx 4.1.15 1.0.0 ga official release):

```
$ git clone git@git.embedian.com:developer/smarc-fsl-linux-kernel.git
$ cd smarc-fsl-linux-kernel
$ git checkout smarc-imx_4.1.15_1.0.0_ga
```

Configure and Build:

```
$ make ARCH=arm CROSS_COMPILE=${CC} distclean
$ make ARCH=arm CROSS_COMPILE=${CC} smarcfmx6_defconfig
$ make ARCH=arm CROSS_COMPILE=${CC} zImage modules imx6q-smarcfmx6.dtb imx6dl-smarcfmx6.dtb imx6qp-smarcfmx6.dtb
```

For 3.14.28 (Based on Freescale imx 3.14.28 1.0.0 ga official release):

```
$ git clone git@git.embedian.com:developer/smarc-fsl-linux-kernel.git
$ cd smarc-fsl-linux-kernel
$ git checkout smarc-imx_3.14.28_1.0.0_ga
```

Note1:

If the board is Dual or Quad core, the device tree blob is imx6q-smarcfmx6.dtb.

If the board is QuadPlus core, the device tree blob is imx6qp-smarcfmx6.dtb.

If the board is Dual Lite or Solo core, the device tree blob is imx6dl-smarcfmx6.dtb

If you are using LVDS panel, replace the corresponding device tree file by the following.

For WVGA (800x480) LVDS panel:

```
imx6q-smarcfmx6.dtb --> imx6q-smarcfmx6-wvga.dtb
imx6dl-smarcfmx6.dtb --> imx6dl-smarcfmx6-wvga.dtb
imx6qp-smarcfmx6.dtb --> imx6qp-smarcfmx6-wvga.dtb
```

For XGA (1024x768) LVDS panel:

```
imx6q-smarcfmx6.dtb --> imx6q-smarcfmx6-xga.dtb
imx6dl-smarcfmx6.dtb --> imx6dl-smarcfmx6-xga.dtb
imx6qp-smarcfmx6.dtb --> imx6qp-smarcfmx6-xga.dtb
```

For WXGA (1366x768) LVDS panel:

```
imx6q-smarcfmx6.dtb --> imx6q-smarcfmx6-wxga.dtb
imx6dl-smarcfmx6.dtb --> imx6dl-smarcfmx6-wxga.dtb
imx6qp-smarcfmx6.dtb --> imx6qp-smarcfmx6-wxga.dtb
```

For 1080p (1920x1080) LVDS panel:

```
imx6q-smarcfmx6.dtb --> imx6q-smarcfmx6-1080p.dtb
imx6dl-smarcfmx6.dtb --> imx6dl-smarcfmx6-1080p.dtb
imx6qp-smarcfmx6.dtb --> imx6qp-smarcfmx6-1080p.dtb
```

Root File System

Ubuntu 16.04:

User	Password
root	root
ubuntu	tempwd

Ubuntu 16.04 Download:

```
$ wget -c ftp://ftp.embedian.com/public/dev/minfs/xenial/imx6-ubuntu-16.04.2-armhf-2017-03-02.tar.gz
```

Verify:

```
$ md5sum imx6-ubuntu-16.04.2-armhf-2017-03-02.tar.gz
0a3b5cf7b2f6c65856e07f21c17f3129  imx6-ubuntu-16.04.2-armhf-2017-03-02.tar.gz
```

Debian 8.7:

User	Password
root	root
debian	tempwd

Debian 8 Download:

```
$ wget -c ftp://ftp.embedian.com/public/dev/minfs/jessie/imx6-debian-8.7-armhf-2017-03-02.tar.gz
```

Verify:

```
$ md5sum imx6-debian-8.7-armhf-2017-03-02.tar.gz
beb77ef08400cb9f1780e8a80f47add6  imx6-debian-8.7-armhf-2017-03-02.tar.gz
```

Ubuntu 14.04:

User	Password
root	root
ubuntu	tempwd

Ubuntu 14.04 Download:

```
$ wget -c ftp://ftp.embedian.com/public/dev/minfs/trusty/imx6-ubuntu1404.tar.gz
```

Verify:

```
$ md5sum imx6-ubuntu1404.tar.gz
f1420197b9581468f586ae3a4181b125  imx6-ubuntu1404.tar.gz
```

Yocto Build Root File System:

User	Password
root	N/A

Find the yocto pre-built root file systems here at [Embedian's ftp site](#) based on your module CPU variants.

Setup SD Card

For these instruction, we are assuming: DISK=/dev/mmcblk0, "lsblk" is very useful for determining the device id.

```
$ export DISK=/dev/mmcblk0
```

Erase SD card:

```
$ sudo dd if=/dev/zero of=${DISK} bs=1M count=16
```

Create Partition Layout:

With util-linux v2.26, sfdisk was rewritten and is now based on libfdisk.

```
sfdisk  
$ sudo sfdisk --version  
sfdisk from util-linux 2.27.1
```

Create Partitions:

```
i sfdisk >=2.26.x  
$ sudo sfdisk ${DISK} <<--__EOF__  
1M,48M,0x83,*  
,,-  
__EOF__
```

```
i sfdisk <=2.25  
$ sudo sfdisk --in-order --Linux --unit M ${DISK} <<--__EOF__  
1,48,0x83,*  
,,-  
__EOF__
```

Format Partitions:

```
for: DISK=/dev/mmcblk0  
$ sudo mkfs.vfat -F 16 ${DISK}p1 -n boot  
$ sudo mkfs.ext4 ${DISK}p2 -L rootfs  
  
for: DISK=/dev/sdX  
$ sudo mkfs.vfat -F 16 ${DISK}1 -n boot  
$ sudo mkfs.ext4 ${DISK}2 -L rootfs
```

Mount Partitions:

On some systems, these partitions may be auto-mounted...

```
$ sudo mkdir -p /media/boot/  
$ sudo mkdir -p /media/rootfs/  
  
for: DISK=/dev/mmcblk0
```



```
$ sudo mount ${DISK}p1 /media/boot/
$ sudo mount ${DISK}p2 /media/rootfs/

for: DISK=/dev/sdX
$ sudo mount ${DISK}1 /media/boot/
$ sudo mount ${DISK}2 /media/rootfs/
```

Install Bootloader

If SPI NOR Flash is not empty

The `u-boot.imx` is pre-installed in SPI NOR flash at factory default. SMARC-FiMX6 is designed to always boot up from SPI NOR flash and to load zImage, device tree blob and root file systems based on the setting of `BOOT_SEL`. If users need to fuse their own u-boot or perform u-boot upgrade. This section will instruct you how to do that.

Copy `u-boot.imx` to the boot partition. (Note: Rename `u-boot-dtb.img` to `u-boot.img` if your u-boot is v2017.03)

~/smarcfmx6-uboot

```
$ sudo cp -v u-boot.imx /media/boot/u-boot.imx
```

Fuse `u-boot.imx` to the SPI NOR flash.

Stop at U-Boot command prompt (Press any key when booting up). Copy and Paste the following script under u-boot command prompt.

u-boot command prompt

```
U-Boot# mmc rescan; mmc dev; load mmc 0:1 0x10800000 u-boot.imx; sf probe; sleep 2; sf erase 0 0xc0000;
sf write 0x10800000 0x400 86000
```

If SPI NOR Flash is empty

In some cases, when SPI NOR flash is erased or the u-boot is under development, we need a way to boot from SD card first. Users need to shunt cross the **TEST#** pin to ground. In this way, *SMARC-FiMX6* will always boot up from SD card.

Copy `u-boot.imx` to the boot partition. (Note: Rename `u-boot-dtb.img` to `u-boot.img` if your u-boot is v2017.03)

~/smarcfmx6-uboot

```
$ sudo dd if=u-boot.imx of=${DISK} bs=512 seek=2
```



1. If your u-boot hasn't been finalized and still under development, it is recommended to shunt cross the test pin and boot directly from SD card first. Once your u-boot is fully tested and finalized, you can fuse your u-boot to SPI NOR flash.
2. When **TEST#** pin of SMARC-FiMX6 is not shunt crossed, it will always boot up from SPI NOR flash. U-boot will read the `BOOT_SEL` configuration and determine where it should load zImage and device tree blob. When **TEST#** is shunt crossed (pull low), it will always boot up from SD card.

uEnv.txt based bootscrip

Create "uEnv.txt" boot script: (\$ vim uEnv.txt)

~/uEnv.txt

```
#####HDMI#####
#optargs="video=mxcfb0:dev=hdmi,1280x720M@60,if=RGB24,bpp=32 consoleblank=0"
#####LVDS#####
#optargs="video=mxcfb0:dev=ldb,if=RGB24,bpp=32 consoleblank=0 fbmem=24M vmlloc=400M"
#####Parallel LCD Setting#####
#optargs="video=mxcfb0:dev=lcd,CLAA-WVGA,if=RGB24,bpp=32 consoleblank=0 fbmem=24M vmlloc=400M"
#####Parallel LCD to CH7055A (VESA Timing Format) Setting #####
```

```
#optargs="video=mxcfb0:dev=lcd,768x576M@75,if=RGB24,bpp=32 consoleblank=0"
#optargs="video=mxcfb0:dev=lcd,1280x1024M@60,if=RGB24,bpp=32 consoleblank=0"
#optargs="video=mxcfb0:dev=lcd,640x480M@60,if=RGB24,bpp=32 consoleblank=0"

console=ttyMXC4,115200
mmcdev=0
mmcpart=1
image=zImage
loadaddr=0x12000000
fdt_addr=0x18000000
mmccroot=/dev/mmcblk1p2 ro
mmccrootfstype=ext4 rootwait fixrtc
netdev=eth0
ethact=FEC0
ipaddr=192.168.1.150
serverip=192.168.1.53
gatewayip=192.168.1.254
mmccargs=setenv bootargs console=${console} root=${mmccroot} rootfstype=${mmccrootfstype} ${optargs}
uenvcmd=run loadimage; run loadfdt; run mmcboot
```

Copy uEnv.txt to the boot partition:

```
~/
$ sudo cp -v ~/uEnv.txt /media/boot/
```

Install Kernel zImage

Copy zImage to the boot partition:

```
~/smarc-fsl-linux-kernel
$ sudo cp -v arch/arm/boot/zImage /media/boot
```

Install Kernel Device Tree Binary

```
$ sudo mkdir -p /media/boot/dtbs
$ sudo cp -v arch/arm/boot/dts/imx6q-smarcfimx6.dtb arch/arm/boot/dts/imx6dl-smarcfimx6.dtb arch/arm/boot/dts/imx6qp-smarcfimx6.dtb /media/boot/dtbs
```



Note

1. If you are using LVDS panel, copy the corresponding device tree blob into SD card as follows.

For WVGA (800x480) LVDS panel:

```
$ sudo cp -v arch/arm/boot/dts/imx6q-smarcfimx6-wvga.dtb /media/boot/dtbs/imx6q-smarcfimx6.dtb
$ sudo cp -v arch/arm/boot/dts/imx6dl-smarcfimx6-wvga.dtb /media/boot/dtbs/imx6dl-smarcfimx6.dtb
$ sudo cp -v arch/arm/boot/dts/imx6qp-smarcfimx6-wvga.dtb /media/boot/dtbs/imx6qp-smarcfimx6.dtb
```

For XGA (1024x768) LVDS panel:

```
$ sudo cp -v arch/arm/boot/dts/imx6q-smarcfimx6-xga.dtb /media/boot/dtbs/imx6q-smarcfimx6.dtb
$ sudo cp -v arch/arm/boot/dts/imx6dl-smarcfimx6-xga.dtb /media/boot/dtbs/imx6dl-smarcfimx6.dtb
$ sudo cp -v arch/arm/boot/dts/imx6qp-smarcfimx6-xga.dtb /media/boot/dtbs/imx6qp-smarcfimx6.dtb
```

For WXGA (1366x768) LVDS panel:

```
$ sudo cp -v arch/arm/boot/dts/imx6q-smarcfimx6-wxga.dtb /media/boot/dtbs/imx6q-smarcfimx6.dtb
$ sudo cp -v arch/arm/boot/dts/imx6dl-smarcfimx6-wxga.dtb /media/boot/dtbs/imx6dl-smarcfimx6.dtb
$ sudo cp -v arch/arm/boot/dts/imx6qp-smarcfimx6-wxga.dtb /media/boot/dtbs/imx6qp-smarcfimx6.dtb
```

For 1080p (1920x1080) LVDS panel:

```
$ sudo cp -v arch/arm/boot/dts/imx6q-smarcfimx6-1080p.dtb /media/boot/dtbs/imx6q-smarcfimx6.dtb
$ sudo cp -v arch/arm/boot/dts/imx6dl-smarcfimx6-1080p.dtb /media/boot/dtbs/imx6dl-smarcfimx6.dtb
$ sudo cp -v arch/arm/boot/dts/imx6qp-smarcfimx6-1080p.dtb /media/boot/dtbs/imx6qp-smarcfimx6.dtb
```

Install Root File System and Kernel Modules

Copy Root File System:

Yocto Pre-Built Rootfs:

directory where your root file system is

```
$ sudo tar xvfz <filename.tar.gz> -C /media/rootfs
```

Ubuntu 14.04:

directory where your root file system is

```
$ sudo tar xvfz imx6-ubuntu1404.tar.gz -C /media/rootfs
```

Copy Kernel Modules:

~/smarc-fsl-linux-kernel

```
$ sudo make ARCH=arm INSTALL_MOD_PATH=/media/rootfs modules_install
```



Note

1. After compiled u-boot, it will generated u-boot.imx and u-boot.bin. The only difference is IVT header that will tell i.MX6 internal ROM where to load u-boot. If the firmware in SPI flash need to be update or empty. Users could pull the *TEST#* pin on carrier board to **low**. In this way, *SMARC-FiMX6* will boot up to SD card first. The u-boot we need to use now will be *u-boot.imx*. The command to copy u-boot.imx to SD card now is:

```
$ sudo dd if=u-boot.imx of=${DISK} bs=512 seek=2
```

In this case, user will only need to copy *uEnv.txt*, *zImage* and *device tree blob* to partition one of your boot device.
2. MAC address is factory pre-installed at on board I2C EEPROM at offset 60 bytes. It starts with Embedian's vendor code *10:0D:32*. u-boot will read it and pass this parameter to kernel.
3. If your rootfs is yocto built, the kernel modules will be included in the rootfs.

Networking:

Edit: /etc/network/interfaces

```
$ sudo vim /media/rootfs/etc/network/interfaces
```

Add:

/media/rootfs/etc/network/interfaces

```
auto lo
iface lo inet loopback

auto eth0
iface eth0 inet dhcp
```

Remove SD card:

```
$ sync
$ sudo umount /media/boot
```

```
$ sudo umount /media/rootfs
```

Setup eMMC

Setting up eMMC usually is the last step at development stage after the development work is done at your SD card or NFS environments. From software point of view, eMMC is nothing but a non-removable SD card on board. For *SMARC-FiMX6*, the SD card is always emulated as `/dev/mmcblk1` and on-module eMMC is always emulated as `/dev/mmcblk3`. Setting up eMMC now is nothing but changing the device descriptor.

This section gives a step-by-step procedure to setup eMMC flash. Users can write a shell script your own at production to simplify the steps.

First, we need to backup the final firmware from your SD card or NFS.

Prepare for eMMC binaries from SD card (or NFS):

Insert SD card into your Linux PC. For these instructions, we are assuming: `DISK=/dev/mmcblk0`, "lsblk" is very useful for determining the device id.

For these instruction, we are assuming: `DISK=/dev/mmcblk0`, "lsblk" is very useful for determining the device id.

```
$ export DISK=/dev/mmcblk0
```

Mount Partitions:

On some systems, these partitions may be auto-mounted...

```
$ sudo mkdir -p /media/boot/  
$ sudo mkdir -p /media/rootfs/  
  
for: DISK=/dev/mmcblk0  
$ sudo mount ${DISK}p1 /media/boot/  
$ sudo mount ${DISK}p2 /media/rootfs/  
  
for: DISK=/dev/sdX  
$ sudo mount ${DISK}1 /media/boot/  
$ sudo mount ${DISK}2 /media/rootfs/
```

Copy zImage to rootfs partition:

```
$ sudo cp -v /media/boot/zImage /media/rootfs/home/root
```



Note

1. If your rootfs is Ubuntu 14.04, copy to `/media/rootfs/home/ubuntu` instead of `/media/rootfs/home/root`

Copy uEnv.txt to rootfs partition:

Copy and paste the following contents to `/media/rootfs/home/root` (`$ sudo vim /media/rootfs/home/root/uEnv.txt`)

```
#####HDMI#####  
#optargs="video=mxcfb0:dev=hdmi,1280x720M@60,if=RGB24,bpp=32 consoleblank=0"  
#####LVDS#####  
#optargs="video=mxcfb0:dev=ldb,if=RGB24,bpp=32 consoleblank=0 fbmem=24M vmlloc=400M"  
#####Parallel LCD Setting#####  
#optargs="video=mxcfb0:dev=lcd,CLAA-WVGA,if=RGB24,bpp=32 consoleblank=0 fbmem=24M vmlloc=400M"  
#####Parallel LCD to CH7055A (VESA Timing Format) Setting #####
```

```

#optargs="video=mxcfb0:dev=lcd,768x576M@75,if=RGB24,bpp=32 consoleblank=0"
#optargs="video=mxcfb0:dev=lcd,1280x1024M@60,if=RGB24,bpp=32 consoleblank=0"
#optargs="video=mxcfb0:dev=lcd,640x480M@60,if=RGB24,bpp=32 consoleblank=0"

console=ttymxc4,115200
mmcdev=2
mmcpart=1
image=zImage
loadaddr=0x12000000
fdt_addr=0x18000000
mmccroot=/dev/mmcblk3p2 ro
mmccrootfstype=ext4 rootwait fixrtc
netdev=eth0
ethact=FEC0
ipaddr=192.168.1.150
serverip=192.168.1.53
gatewayip=192.168.1.254
mmccargs=setenv bootargs console=${console} root=${mmccroot} rootfstype=${mmccrootfstype} ${optargs}
uenvcmd=run loadimage; run loadfdt; run mmcboot

```

Copy device tree blob to rootfs partition:

```

$ sudo cp -v /media/boot/dtbs/imx6q-smarcfmx6.dtb /media/rootfs/home/root/imx6q-smarcfmx6.dtb
$ sudo cp -v /media/boot/dtbs/imx6dl-smarcfmx6.dtb /media/rootfs/home/root/imx6dl-smarcfmx6.dtb

```



Note

1. If you are using LVDS panel, copy the corresponding device tree blob into eMMC as follows.

For WVGA (800x480) LVDS panel:

```

$ sudo cp -v arch/arm/boot/dts/imx6q-smarcfmx6-wvga.dtb /media/boot/dtbs/imx6q-smarcfmx6.dtb
$ sudo cp -v arch/arm/boot/dts/imx6dl-smarcfmx6-wvga.dtb /media/boot/dtbs/imx6dl-smarcfmx6.dtb

```

For XGA (1024x768) LVDS panel:

```

$ sudo cp -v arch/arm/boot/dts/imx6q-smarcfmx6-xga.dtb /media/boot/dtbs/imx6q-smarcfmx6.dtb
$ sudo cp -v arch/arm/boot/dts/imx6dl-smarcfmx6-xga.dtb /media/boot/dtbs/imx6dl-smarcfmx6.dtb

```

For WXGA (1366x768) LVDS panel:

```

$ sudo cp -v arch/arm/boot/dts/imx6q-smarcfmx6-wxga.dtb /media/boot/dtbs/imx6q-smarcfmx6.dtb
$ sudo cp -v arch/arm/boot/dts/imx6dl-smarcfmx6-wxga.dtb /media/boot/dtbs/imx6dl-smarcfmx6.dtb

```

For 1080p (1920x1080) LVDS panel:

```

$ sudo cp -v arch/arm/boot/dts/imx6q-smarcfmx6-1080p.dtb /media/boot/dtbs/imx6q-smarcfmx6.dtb
$ sudo cp -v arch/arm/boot/dts/imx6dl-smarcfmx6-1080p.dtb /media/boot/dtbs/imx6dl-smarcfmx6.dtb

```

Copy real rootfs to rootfs partition:

Yocto Built Root File Systems

```

$ pushd /media/rootfs
$ sudo tar cvfz ~/smarcfmx6-emmc-rootfs.tar.gz .
$ sudo mv ~/smarcfmx6-emmc-rootfs.tar.gz /media/rootfs/home/root
$ popd

```

Ubuntu 14.04 Root File Systems

```

$ sudo vim /media/rootfs/etc/udev/rules.d/70-persistent-net.rules
Delete all contents starting with "SUBSYSTEM=="
$ pushd /media/rootfs
$ sudo tar cvfz ~/smarcfmx6-emmc-rootfs.tar.gz .

```

```
$ sudo mv ~/smarcfimx6-emmc-rootfs.tar.gz /media/rootfs/home/root
$ popd
```

Remove SD card:

```
$ sync
$ sudo umount /media/boot
$ sudo umount /media/rootfs
```

Copy Binaries to eMMC from SD card:

Insert this SD card into your SMARC-FiMX6 device and boot into SD card.

Now it will be almost the same as you did when setup your SD card, but the eMMC device descriptor is `/dev/mmcblk3` now.

```
$ export DISK=/dev/mmcblk3
```

Erase SD card:

```
$ sudo dd if=/dev/zero of=${DISK} bs=1M count=16
```

Create Partition Layout:

```
$ sudo sfdisk --in-order --Linux --unit M ${DISK} <<--__EOF__
1,48,0x83,*
,,,-
__EOF__
```

Format Partitions:

```
$ sudo mkfs.vfat -F 16 ${DISK}p1 -n boot
$ sudo mkfs.ext4 ${DISK}p2 -L rootfs
```

Mount Partitions:

```
$ sudo mkdir -p /media/boot/
$ sudo mkdir -p /media/rootfs/
$ sudo mount ${DISK}p1 /media/boot/
$ sudo mount ${DISK}p2 /media/rootfs/
```

Install binaries for partition 1

Copy `uEnv.txt/zImage/*.dtb` to the boot partition

```
$ sudo cp -v zImage uEnv.txt /media/boot/
```

Install Kernel Device Tree Binary

```
$ sudo mkdir -p /media/boot/dtbs
$ sudo cp -v imx6q-smarcfimx6.dtb imx6dl-smarcfimx6.dtb /media/boot/dtbs
```

Install Root File System

```
$ sudo tar -zxvf smarcfmx6-emmc-rootfs.tar.gz -C /media/rootfs
```

Unmount eMMC:

```
$ sync
$ sudo umount /media/boot
$ sudo umount /media/rootfs
```

Switch your Boot Select to eMMC and you will be able to boot up from eMMC now.

version 1.0a, 3/23/2015

Last updated 2018-02-08